

## TECHNICAL DATA

# Fluke 113 Utility Multimeter



### True-rms utility multimeter designed for basic electrical tests

The new 113 Utility Multimeter has the features needed to repair most electrical problems. This meter is simple to use and has significant improvements over other utility multimeters. With features such as Fluke's VCHEK™, added measurement functions, backlight, conformance to the latest safety standards, and a much larger display that's easier to view, this new meter is a must have for the utility users toolbox.

### Features

- VCHEK™ LoZ low impedance measurement function to simultaneously test for voltage and continuity
- True-rms for accurate ac measurements on non-linear loads
- A large backlit display allows for easy visibility in low-lit areas
- Record signal fluctuations using the Min/Max function
- Diode test for testing general-purpose germanium, silicon, and power diodes
- Integral holster with probe holders for easy storage
- Auto and Manual ranging for added user functionality
- Meets Measurement Category CAT IV 600 V standards for a higher level of safety
- The optional TPAK magnetic hanger allows the user hands-free flexibility

### APPLICATIONS

- Designed for basic electrical tests
- Electrical testing where ghost voltage may be present

## Specifications

Accuracy is specified for 1 year after calibration, at operating temperatures of 18 °C to 28 °C, with relative humidity at 0 % to 95 %. Accuracy specifications are given as follows:

| Function                                                                                                     | Range                                      | Resolution                        | Accuracy                                                                                  |                 |
|--------------------------------------------------------------------------------------------------------------|--------------------------------------------|-----------------------------------|-------------------------------------------------------------------------------------------|-----------------|
|                                                                                                              |                                            |                                   | DC, 45 to 500 Hz                                                                          | 500 Hz to 1 kHz |
|  <b>Chek</b> <sup>1,2</sup> | 6.000 V<br>60.00 V<br>600.0 V              | 0.001 V<br>0.01 V<br>0.1 V        | 2.0 % + 3                                                                                 | 4.0 % + 3       |
|  <sup>3</sup>               | 2.000 V                                    | 0.001 V                           | 2.0 % + 3                                                                                 |                 |
|  <sup>3</sup>               |                                            |                                   | Beeper on < 20 Ω, off > 250 Ω; detects opens or shorts of 500 μs or longer                |                 |
|  <sup>3</sup>               | 600.0 Ω<br>6.000 kΩ<br>60.00 kΩ            | 0.1 Ω<br>0.001 kΩ<br>0.01 kΩ      | 0.9 % + 2<br>0.9 % + 1<br>0.9 % + 1                                                       |                 |
|  <sup>3</sup>               | 1000 nF<br>10.00 μF<br>100.0 μF<br>9999 μF | 1 nF<br>0.01 μF<br>0.1 μF<br>1 μF | 1.9 % + 2<br>1.9 % + 2<br>1.9 % + 2<br>100 μF – 1000 μF: 1.9 % + 2<br>> 1000 μF: 5 % + 20 |                 |

1 All  Chek voltage ranges are specified from 60 counts to 100 % of range. Because inputs below 60 counts are not specified, it is possible and normal for this and other true-rms meters to display non-zero readings when the test leads are disconnected from a circuit or are shorted together.

2 Crest factor of ≤ 3 at 4000 counts, decreasing linearly to 1.5 at full scale.

3 After measuring voltage, a wait time of 1 minute is required to maintain accuracy of ohms, capacitance, diode test, and continuity.

Note: Specifications are subject to change without notice. ± ( [ % of reading ] + [ number of least significant digits ] )

| General specifications                                     |                                                                 |
|------------------------------------------------------------|-----------------------------------------------------------------|
| Maximum voltage<br>(between any terminal and earth ground) | 600 V                                                           |
| Display                                                    | 3 3/4-digits, 6000 counts, updates 4/sec                        |
| Operating temperature                                      | -10 °C to 50 °C (14 °F to 122 °F)                               |
| Storage temperature                                        | -40 °C to 60 °C (-22 °F to 140 °F)                              |
| Temperature coefficient                                    | 0.1 x (specified accuracy)/°C (< 18 °C or > 28 °C)              |
| Operating altitude                                         | 2,000 m                                                         |
| Storage altitude                                           | 10,000 m                                                        |
| Relative humidity                                          | 95 % to 30 °C<br>75 % to 40 °C<br>45 % to 50 °C                 |
| Battery type                                               | 9 Volt Alkaline, IEC 6LR61                                      |
| Battery life                                               | Alkaline: 300 hours typical, without backlight                  |
| Size (HxWxL)                                               | 167.1 mm X 85.1 mm X 46.0 mm (6.58 in X 3.35 in X 1.81 in)      |
| Weight                                                     | 13.0 oz (404 g)                                                 |
| Safety                                                     | IEC 61010-1, Pollution Degree 2<br>IEC 61010-2-033 CAT IV 600 V |
| EMC                                                        | 61326-1:Portable                                                |

## Specifications (continued)

| Function                                                                               | Input impedance (nominal)                             |                    |
|----------------------------------------------------------------------------------------|-------------------------------------------------------|--------------------|
|  Chek | ~3 k $\Omega$ < 300 pF                                |                    |
|                                                                                        | Common Mode Rejection Ratio (1 k $\Omega$ Unbalanced) |                    |
|       | > 60 dB at dc, 50 or 60 Hz                            |                    |
|                                                                                        | Open circuit test voltage                             | Full scale voltage |
| $\Omega$                                                                               | < 2.7 V dc                                            | < 0.7 V dc         |
|       | < 2.7 V dc                                            | 2.000 V dc         |
|                                                                                        | Short circuit current                                 |                    |
| $\Omega$                                                                               | < 350 $\mu$ A                                         |                    |
|       | < 1.0 mA                                              |                    |

## Ordering information

**Fluke 113** Utility Multimeter

### Included

**Fluke 113** Utility Multimeter

**TL75** Test Leads

One 9 V battery

User documentation

**Fluke.** *Keeping your world up and running.®*

### Fluke Corporation

PO Box 9090, Everett, WA 98206 U.S.A.

### Fluke Europe B.V.

PO Box 1186, 5602 BD  
Eindhoven, The Netherlands

### For more information call:

In the U.S.A. (800) 443-5853 or  
Fax (425) 446-5116  
In Europe/M-East/Africa +31 (0)40 267 5100 or  
Fax +31 (0)40 267 5222  
In Canada (800)-36-FLUKE or  
Fax (905) 890-6866  
From other countries +1 (425) 446-5500 or  
Fax +1 (425) 446-5116  
Web access: <http://www.fluke.com>

©2008, 2020 Fluke Corporation.  
Specifications subject to change without notice.  
Printed in U.S.A. 1/2020 3292015b-en

**Modification of this document is not permitted without written permission from Fluke Corporation.**

# Diensten van EURO-INDEX

**EURO-INDEX is fabrikant, importeur en distributeur van diverse A-merken op het gebied van test- en meetinstrumenten. Daarnaast leveren wij een groot aantal diensten om het gebruik van deze instrumenten in uw bedrijfsvoering te optimaliseren. Dit omvat uiteraard onderhoud, reparatie en kalibratie van de instrumenten, maar ook kennisdeling via de EURO-INDEX Academy en verhuur van instrumenten.**

## Geautoriseerd Service Centrum

EURO-INDEX b.v. is van alle vertegenwoordigde merken een Geautoriseerd Service Centrum. Dit betekent dat uw instrumenten worden behandeld door technici die zijn opgeleid door de fabrikant en beschikken over de juiste gereedschappen en software. Er worden uitsluitend originele onderdelen toegepast en de garantie van uw instrument, evenals de certificering (ATEX, EN50379, etc.) blijven intact.

## Kalibratielaboratorium

Ons moderne service- en kalibratielaboratorium beschikt over een RvA accreditatie naar NEN-EN-ISO/IEC 17025. Deze accreditatie geldt voor grootheden, zoals gespecificeerd in de scope bij accreditatienummer K105.



**Kijk voor een overzicht van al onze diensten op [euro-index.nl/diensten](http://euro-index.nl/diensten)**



## Mobiele Service

Naast de vaste kalibratielaboratoria in Capelle aan den IJssel en Zaventem beschikken wij ook over laboratoria op wielen met de naam "Mobiele Service". Dit biedt vertrouwde service en kwaliteit, bij u voor de deur!

## KWS®

KWS® is een uniek servicesysteem voor uw meetinstrumenten met periodiek onderhoud en kalibratie tegen vaste, lage kosten. Uw kalibratiecertificaten zijn digitaal beschikbaar via Mijn KWS (gratis webportaal en app).

## Verhuur van meetinstrumenten

- Uitgebreid assortiment
- Nauwkeurigheid aantoonbaar door actueel kalibratiecertificaat
- Deskundig advies
- Complete levering inclusief accessoires

## EURO-INDEX Academy

- Trainingen (individueel en klassikaal)
- Cursussen en workshops
- Demonstratie- en instructievideo's
- Whitepapers



Servicebalie



Onderhoud, reparatie en kalibratie



Cursussen en workshops



Mobiele Service

Wijzigingen voorbehouden EURO-INDEX® NL 24005



**NETHERLAND**  
Rivium 2e straat 12  
2909 LG Capelle a/d IJssel  
T: 010 - 2 888 000  
F: 010 - 2 888 010  
[verkoop@euro-index.nl](mailto:verkoop@euro-index.nl)  
[www.euro-index.nl](http://www.euro-index.nl)



**BELGIË**  
Leuvensesteenweg 607  
1930 Zaventem  
T: +32 - (0)2 - 757 92 44  
F: +32 - (0)2 - 757 92 64  
[info@euro-index.be](mailto:info@euro-index.be)  
[www.euro-index.be](http://www.euro-index.be)