

# METRACELL BT PRO

## Portable Battery Tester

3-447-057-03  
3/12.22

- Measurement of block voltages
- Measurement of overall voltages up to 600 V<sub>DC</sub> and 300 V<sub>AC</sub>
- Capacity tests of individual blocks and entire batteries
- Internal resistance measurement with simultaneous measurement of the electric resistance ( $R_{el}$ )<sup>1</sup> and electrochemical (charge-transfer) resistance ( $R_{ct}$ )<sup>2</sup> for the determination of the battery status with the highest possible degree of accuracy
- Measurement of voltage drops at connectors
- Automated recording of voltage and current curves (current curves with optional sensor technology)
- Measurement of block temperatures (with optional sensor technology)
- Import of density values by directly connecting a DMA 35 density sensor from Anton Paar GmbH
- Mobile and safe usage in the field thanks to convenient carrying options and rugged design
- Battery identification by means of RFID tag reader
- Storage of up to 300,000 data records
- Multilingual battery tester management software for the management of battery databases and measurement data as well as for the analysis of measurement data including the generation of meaningful reports
- Wireless transmission of measurement data



## Applications

Periodic testing and well-organized maintenance are necessary in order to assure the availability of stationary battery systems. The METRACELL BT PRO is a universal, multifunctional test instrument for user-friendly, professional maintenance of these battery systems. It can be used to determine the current status of the battery or battery block and pinpoint hidden battery defects. The battery tester is used primarily for testing stationary battery systems.



Figure 1: Carrying case (left), analysis of measurement data (right)

## Features

- Simple and intuitive menu structure
- Easy-to-understand display of measured values
- Illuminated high-contrast display
- Compact design and shockproof ABS housing with additional rubber holster
- Unrestricted motion thanks to carrying strap, fastening clip and magnet
- Automatic measured value acquisition with acoustic feedback
- Integrated wireless interface
- Integrated infrared interface
- Operating time approx. 10 hours
- Battery operation, equipped with 4 NiMH rechargeable batteries and battery charger as standard equipment
- Kelvin probes for 4-wire measurement (suppress influence of cable and contact resistances on the resistance measurement results)
- Carrying case for the safe storage of test instrument and accessories
- PC-aided management, evaluation and storage of measured values

1) Electrical Resistance  $R_{el}$

is a measure of strictly electrical losses. These losses occur at, for example, plate straps, plate grids and electrolytes. The battery delivers rapidly changing currents via this resistance, for example for switched-mode DC/DC converters. Together with  $R_{ct}$ , it adds up to the  $R_{DC}$  (direct current resistance) of a battery.

2) Charge Transfer Resistance  $R_{ct}$

Characterizes the ability of a block to accumulate and release a charge. This makes it possible to identify battery blocks (with electro-chemical defects) which are operating at a loss during float. Together with  $R_{el}$ , it adds up to the  $R_{DC}$  (direct current resistance) of a battery.

# METRACELL BT PRO

## Portable Battery Tester

### Measurements

Measurement	Description
MULTIMETER	DC and AC voltage measurements without storing measured values.
FLOAT	Periodic measurement of block voltages. This measurement is used for the frequent recording of the float voltage level of battery blocks, for example in UPS systems.
DISCHARGE	Multiple measurement of block voltages at short intervals during a discharge cycle (capacity tests of blocks).
CHARGE	Multiple measurement of block voltages at short intervals during a charge cycle (capacity tests of blocks).
RESISTANCE	Periodic measurement of the internal resistance of the blocks
TEMPERATURE	Measurement of block temperature with an IR temperature sensor
CONNECTOR	Measurement of voltage drop to determine connector loss between blocks
INTERVAL U	Measurement of the voltage of a battery at any desired time interval (voltage curve / capacity test of the entire battery).
INTERVAL U + I	Measurement of the voltage and current of a battery at any desired time interval (voltage and current curves) / capacity test of the entire battery). Example: Recording of discharge current during discharging.
DMA 35 (IrDA)	Measurement of acid density and electrolyte temperature within a block. Measurements are performed with the DMA 35 density meter (version 3) from Anton Paar GmbH.
DMA 35 (BT)	Measurement of acid density and electrolyte temperature within a block. Measurements are performed with the DMA 35 density meter (version 4) from Anton Paar GmbH.

### Measurement Inputs

Mea-sure-ment Input	Function	Mea-sure-ment Input	Function
S-	Input for measuring DC voltage. Measuring range: $\pm 2450.00 \text{ mV}_{\text{DC}}$ Resolution: 0.01 mV Input impedance: $>10 \text{ M}\Omega$ Sensing lead to minus pole during resistance measurement.	S+	Measurement input for direct and alternating voltage measurements. Measuring ranges: $\pm 24.500 \text{ V}_{\text{DC}}$ Resolution: 0.1 mV $\pm 600.000 \text{ V}_{\text{DC}}$ Resolution: 1 mV $0...300.00 \text{ V}_{\text{AC}}$ Resolution: 10 mV Input impedance: $1.6 \text{ M}\Omega$ Sensing lead to plus pole during resistance measurement.
P-/COM	Reference potential (ground potential) of all measurement inputs. Current conducting cable to minus pole during resistance measurement.	P+	Current conducting cable to plus pole during resistance measurement.   <b>Attention!</b> <b>Max. 24 V<sub>DC</sub></b> Maximum test voltage must not exceed 24 V <sub>DC</sub> at input P+. The instrument is damaged if this value is exceeded.



#### Note

600 V CAT III refers to measurement inputs S+, S- and P-/COM.

# METRACELL BT PRO

## Portable Battery Tester

### Relevant Standards

The battery tester has been manufactured and tested in accordance with the following safety regulations:

IEC 61010-1	Safety requirements for electrical equipment for measurement, control and laboratory use
EN 61010-1	– General requirements
VDE 0411-1	
EN 60529	Test instruments and test procedures
VDE 0470-1	Degrees of protection provided by enclosures (IP code)
DIN EN 61326-1	Electrical equipment for measurement, control and laboratory use – EMC requirements –
VDE 0843-20-1	Part 1: General requirements

### Characteristic Values

Measuring Function	Multimeter/Connector	Multimeter/Float/Discharge/Charge	Multimeter/Interval U / Interval U+I	Multimeter	Resistance	Temperature
Measured Quantity	$V_{DC}$	$V_{DC}$	$V_{DC}$	$V_{AC}$ <sup>1)</sup>	$R_{el} + R_{ct}$	°C
Display Range	-2450.00 ... +2450.00 mV	-24.5000 ... +24.5000 V	-600.000 ... +600.000 V	0.00 ... 300.00 V	00.00 ... 1000.00 mΩ	-230.0 ... +230.0 °C <sup>2)</sup>
Measuring Range	-2450.00 ... +2450.00 mV	-24.5000 ... +24.5000 V	-600.000 ... +600.000 V	0.00 ... 300.00 V	00.10 ... 1000.00 mΩ	
Frequency Display	-	-	-	40.00 - 99.99 Hz 100.0 - 999.9 Hz 1000 - 1400 Hz <sup>3)</sup>	-	-
Resolution	0.01 mV	0.1 mV	1 mV	10 mV	0.01 mΩ	0.1 °C
Input Impedance/Test Current	>10 MΩ	1.6 MΩ	1.6 MΩ	1.6 MΩ	$I_p$ approx. 2A	>10 MΩ
Intrinsic Uncertainty	±(0.05 % rdg. + 10d)	±(0.05 % rdg. + 10d)	±(0.05 % rdg. + 50d)	±(2.0 % rdg. + 10d) <sup>4)</sup>	±(3.0 % rdg. + 8d)	
S+	Measur-ing Con-nec-tions	•	•	•	•	
S-		•	∞		•	•
P+					•	
P-/COM		•	•	• ∞	•	•

<sup>1)</sup> Frequency measurement only works from an input voltage of 20  $V_{AC}$  onwards.

<sup>2)</sup> only applicable if the temperature sensor is connected to the battery tester.

<sup>3)</sup> The frequency range of 1000 Hz to 1400 Hz is not calibrated. This is indicated in the METRACELL BT PRO display by "NC" (not calibrated).

<sup>4)</sup> within a frequency range of 45 to 500 Hz.

#### Note

The characteristic values of the AC/DC current clamp sensors and the DMA 35 density meter, as well as additional characteristic values for the temperature sensor, can be found in the respective product documentation.

# METRACELL BT PRO

## Portable Battery Tester

### Technical Data

<b>Power Supply</b>	Rechargeable NiMH battery, 4 × 1,2 V type AA, round cells (recommended: Ansmann maxE 2500 mAh)	
<b>Input Impedance</b>	Measuring input S+:	1.6 MΩ
	Measuring input S-:	>10 MΩ
<b>Ambient Conditions</b>	Operating temperatures:	+5 ... +40 °C
	Storage temperatures:	-20 ... +60 °C
	Relative humidity:	max. 75 %, no condensation allowed
	Elevation:	max. 2000 m
<b>Electrical Safety</b>	Measuring category:	600 V CAT III
	Pollution degree:	2
	Protection class:	II
	Fuse link:	1 × SIBA 600 V/10 A FF
	Test voltage:	Test voltage at measuring connection P+ may not exceed 24 VDC.
<b>Electromagnetic Compatibility (EMC)</b>	Interference emission:	EN 61326-1 class A
	Interference immunity:	EN 61326-1 EN 61326-2-1
<b>Mechanical Design</b>	Protection:	Housing IP40 per DIN VDE 0470-1/EN 60529 (protection against foreign object ingress: ≥ 1.0 mm Ø; protection against water ingress : not protected)
	Housing (W × H × D):	approx. 9.6 × 15.4 × 3.3 cm
	Weight:	approx. 0.45 kg (without rubber holster)
	Display:	LCD, monochrome, luminous
<b>Data Interfaces</b>	IrDA:	Connection for DMA 35 Basic density meter (version 3)
	RFID:	Connection for RFID tag Frequency range: 125 kHz Transmission intensity: 34.3 dBµV/m or -17.2 dBµA/m, respectively
	Wireless interface:	Connection for PC, headset and DMA 35 density meter (version 4) Frequency range: 2.4 - 2.4835 GHz Transmission intensity: max. + 3 dBm
<b>Internal Memory</b>	up to 300,000 data records	

# METRACELL BT PRO

## Portable Battery Tester

### Scope of Delivery

- 1 METRACELL BT PRO
- 4 1.2 V round cells
- 1 Power pack
- 1 Rubber holster
- 1 Carrying strap
- 1 Carrying case
- 2 Alligator clips (KY95-3)
- 1 Set of multimeter test probes (Z229B)
- 1 Set of Kelvin probes for 4-wire measurement (Z227D)
- 1 BT PRO Manager (Battery tester management software)
- 1 Test report/factory calibration certificate
- 1 Condensed operating instructions

### Optional Accessories

- AC/DC current clamp sensor
  - CP1800 (Z204A) for measurements up to  $1250 \text{ A}_{\text{DC}}$  or
  - CP330 (Z202B) for measurements up to  $300 \text{ A}_{\text{DC}}$
- Temperature sensor METRATHERM IR BASE (Z680A)
- Angled probes for 4-wire measurement (Z227W)
- Spring-loaded contact pins as replacement parts (Z227F) for the Kelvin probes (Z227D) and angled probes (Z227W)



Figure 2: Battery tester with AC/DC current clamp sensor CP1800 (Z204A)



Figure 3: Battery tester with temperature sensor METRATHERM IR BASE (Z680A)



Figure 4: Kelvin probes with spring-loaded contact pins



Figure 5: Angled probes for 4-wire measurement (Z227W)

# METRACELL BT PRO

## Portable Battery Tester

### Order Information

Description	Type	Article number
Portable, multi-functional device for the testing of batteries and battery blocks; including rechargeable batteries and power pack, alligator clips, set of multimeter test probes, Kelvin probes, software and transport accessories	METRACELL BT PRO	B100B
AC/DC current clamp sensor	CP1800	Z204A
	CP330	Z202B
Temperature sensor	METRATHERM IR BASE	Z680A
Angled probes for 4-wire measurement		Z227W
Spring-loaded contact pins as replacement parts for the Kelvin probes (Z227D) and angled probes (Z227W)		Z227F

---

© Gossen Metrawatt GmbH

Edited in Germany • Subject to change without notice / Errors excepted • A pdf version is available on the Internet

All trademarks, registered trademarks, logos, product names, and company names are property of their respective owners.

# Diensten van EURO-INDEX

**EURO-INDEX is fabrikant, importeur en distributeur van diverse A-merken op het gebied van test- en meetinstrumenten. Daarnaast leveren wij een groot aantal diensten om het gebruik van deze instrumenten in uw bedrijfsvoering te optimaliseren. Dit omvat uiteraard onderhoud, reparatie en kalibratie van de instrumenten, maar ook kennisdeling via de EURO-INDEX Academy en verhuur van instrumenten.**

## Geautoriseerd Service Centrum

EURO-INDEX b.v. is van alle vertegenwoordigde merken een Geautoriseerd Service Centrum. Dit betekent dat uw instrumenten worden behandelt door technici die zijn opgeleid door de fabrikant en beschikken over de juiste gereedschappen en software. Er worden uitsluitend originele onderdelen toegepast en de garantie van uw instrument, evenals de certificering (ATEX, EN50379, etc.) blijven intact.

## Kalibratielaboratorium

Ons moderne service- en kalibratielaboratorium beschikt over een RvA accreditatie naar NEN-EN-ISO/IEC 17025. Deze accreditatie geldt voor grootheden, zoals gespecificeerd in de scope bij accreditatienummer K105.



**Kijk voor een overzicht van al onze diensten op [euro-index.nl/diensten](http://euro-index.nl/diensten)**

## Mobiele Service

Naast de vaste kalibratielaboratoria in Capelle aan den IJssel en Zaventem beschikken wij ook over een laboratorium op wielen met de naam "Mobiele Service". Dit biedt vertrouwde service en kwaliteit, bij u voor de deur!

## KWS®

KWS® is een uniek servicesysteem voor uw meetinstrumenten met periodiek onderhoud en kalibratie tegen vaste, lage kosten. Via een gratis webportal ([mijnkws.nl](http://mijnkws.nl)) heeft u altijd en overal beschikking over uw kalibratiecertificaten.

## Verhuur van meetinstrumenten

- Uitgebreid assortiment
- Nauwkeurigheid aantoonbaar door actueel kalibratiecertificaat
- Deskundig advies
- Complete levering inclusief accessoires

## EURO-INDEX Academy

- Trainingen (individueel en klassikaal)
- Cursussen en workshops
- Demonstratie- en instructievideo's
- Whitepapers



Servicebalie



Onderhoud, reparatie en kalibratie



Cursussen en workshops



Mobiele Service

Wijzigingen voorbehouden EURO-INDEX® NL 21004



NETHERLAND

Rivium 2e straat 12  
2909 LG Capelle a/d IJssel  
T: 010 - 2 888 000  
F: 010 - 2 888 010  
[verkoop@euro-index.nl](mailto:verkoop@euro-index.nl)  
[www.euro-index.nl](http://www.euro-index.nl)



Geaccrediteerde scope  
zie [www.rva.nl](http://www.rva.nl)



BELGIË

Leuvensesteenweg 607  
1930 Zaventem  
T: +32 - (0)2 - 757 92 44  
F: +32 - (0)2 - 757 92 64  
[info@euro-index.be](mailto:info@euro-index.be)  
[www.euro-index.be](http://www.euro-index.be)